



FASTRAX SERIES ACCESSORIES

FASTRAX PAN-TILT-ZOOM DOME CAMERA

CPT-FTD360 - High-resolution PTZ color dome camera, 18X optical zoom; 12X digital zoom.

CPT-FTD360DN - High-resolution PTZ day/night dome camera, 18X optical zoom; 12X digital zoom.

CPT-FTD366DN - High-resolution PTZ day/night dome camera, 26X optical zoom; 12X digital zoom.



VANDAL-RESISTANT PAN-TILT-ZOOM MINITRAX DOME CAMERA

CPT-FTD355 - Versatile indoor/outdoor vandal-resistant dome camera.



CPT-FTD302 - Indoor enclosure includes wall and pendant mounting brackets for CPT-FTD360 Series.



CPT-HCM150 - Corner mount adapter brackets for CPT-FTD360 Series.



CPT-FTD/SD - Smoked dome option for CPT-FTD360 Series.



CPT-FTD12JB - RS422 junction box for CPT-FTD360 Series and CPT-FTD355. Included with the CPT-FTD2404CZ keyboard.



CPT-FTD355HK - Heater kit for CPT-FTD355.



CPT-FTD302SH - Outdoor enclosure includes heater, blower and mounting brackets for CPT-FTD360 Series.



CPT-HCM151 - Pole mount adapter brackets for CPT-FTD360 Series.



CPT-FTD251 - Indoor flush mount kit for CPT-FTD360 Series.

CPT-FTD251/S - With smoke dome.



CPT-FTD/WCM - Wall and ceiling mounting brackets for CPT-FTD355.





THE COMPLETE SURVEILLANCE SYSTEM

FASTRAX SERIES ACCESSORIES

CPT-FTD2404CZ – Full system keyboard controller for CPT-FTD360 Series and CPT-FTD355.

This keyboard is laid out with user-friendly design for efficient operator control. Two keyboards may also be configured into a system when more than one operator is required.

Communication:

- ▶ Dome communication – max 32
- ▶ Multiplexer communication – max 255
- ▶ DVR communication – max 99



CPT-FTD422DA – Distribution amplifier for CPT-FTD360 Series and CPT-FTD355.

This distribution unit is a 16-channel RS-422 transmit-only distributor. The CPT-FTD422DA allows for a star configuration of PTZ cameras.

- ▶ Two 3-position screw terminal connectors, providing an input from a keyboard and an output for an additional daisy-chained distribution unit
- ▶ Sixteen 3-position screw terminal connectors used to output RS-422 transmit signal
- ▶ Power source: 12 VDC input

